

No.	Name	No.	Name	No.	Name	No.	Name
USER	1-1 V-GUITAR	USER	11-1 FatMETAL	USER	21-1 FAT 1959	PRESET	31-1 JAZZ TL
USER	1-2 AcGt12st	USER	11-2 Ac PIEZO	USER	21-2 TELE DRV	PRESET	31-2 BODY 12
USER	1-3 TEXS ST	USER	11-3 f HOLE	USER	21-3 SPACSTRT	PRESET	31-3 PD SHIFT
USER	1-4 OCT DRV	USER	11-4 HARMO 12	USER	21-4 OCT SFX	PRESET	31-4 TL TWIN
USER	2-1 SMOKE ST	USER	12-1 DropD -2	USER	22-1 '80s BG	PRESET	32-1 SPACSTRT
USER	2-2 NYLON	USER	12-2 DETUNE12	USER	22-2 FAT BG	PRESET	32-2 TL+BODY
USER	2-3 STD JAZZ	USER	12-3 BRT LP	USER	22-3 TL+BODY	PRESET	32-3 DarkJAZZ
USER	2-4 ECHO PAD	USER	12-4 BOWED	USER	22-4 SYN LEAD	PRESET	32-4 CLEAN 12
USER	3-1 OD STACK	USER	13-1 WAH TL	USER	23-1 '70s LED	PRESET	33-1 JC CLEAN
USER	3-2 12st+EGt	USER	13-2 ALL E	USER	23-2 TexsLead	PRESET	33-2 Rick12st
USER	3-3 MILD ST	USER	13-3 JAZZ TL	USER	23-3 DarkJAZZ	PRESET	33-3 American
USER	3-4 ORGAN	USER	13-4 DRV BASS	USER	23-4 Bell Mix	PRESET	33-4 '60s BOX
USER	4-1 BG DRV	USER	14-1 MetalWah	USER	24-1 WAH LEAD	PRESET	34-1 335CUTIN
USER	4-2 AcGt+BS	USER	14-2 NASH Gt	USER	24-2 FuzzLead	PRESET	34-2 COOLJAZZ
USER	4-3 WAH STRT	USER	14-3 BODY 12	USER	24-3 CLEAN 12	PRESET	34-3 ST WING
USER	4-4 HORN Gt	USER	14-4 STEP SFX	USER	24-4 BASS AMP	PRESET	34-4 ST LINE
USER	5-1 DeepEcho	USER	15-1 WAH +7	USER	25-1 AngleWAH	PRESET	35-1 SlowGEAR
USER	5-2 LA NYLON	USER	15-2 BANJO	USER	25-2 HARDROCK	PRESET	35-2 EchoJAZZ
USER	5-3 -1OCT ST	USER	15-3 PD SHIFT	USER	25-3 '60sECHO	PRESET	35-3 OCT N.PU
USER	5-4 BASS DRV	USER	15-4 SlowEcho	USER	25-4 BAMBOO	PRESET	35-4 CLEAN ST
USER	6-1 BluesDrv	USER	16-1 MTL SOLO	PRESET	26-1 V-GUITAR	PRESET	36-1 CH JAZZ
USER	6-2 CAPO -4	USER	16-2 CAPO 7	PRESET	26-2 AcGt12st	PRESET	36-2 MildJazz
USER	6-3 BODY	USER	16-3 TL TWIN	PRESET	26-3 TEXS ST	PRESET	36-3 R+F CUT
USER	6-4 PAN SFX	USER	16-4 OCTAVE24	PRESET	26-4 OCT DRV	PRESET	36-4 TwCHORUS
USER	7-1 ES WAH	USER	17-1 CoolLead	PRESET	27-1 SMOKE ST	PRESET	37-1 LP FRONT
USER	7-2 AcGt MIX	USER	17-2 MINI AMP	PRESET	27-2 NYLON	PRESET	37-2 BRT HALF
USER	7-3 TELE MOD	USER	17-3 OPEN E	PRESET	27-3 STD JAZZ	PRESET	37-3 MILD TL
USER	7-4 Em9	USER	17-4 AnalogGR	PRESET	27-4 ECHO PAD	PRESET	37-4 TELE BRT
USER	8-1 LP WAH	USER	18-1 FatBlues	PRESET	28-1 OD STACK	PRESET	38-1 CLN-LEAD
USER	8-2 12ST AG	USER	18-2 DRV-@CLN	PRESET	28-2 12st+EGt	PRESET	38-2 COMP JC
USER	8-3 CLEAN TL	USER	18-3 STRATCru	PRESET	28-3 MILD ST	PRESET	38-3 RICK CLN
USER	8-4 ROTARY	USER	18-4 12st OCT	PRESET	28-4 ORGAN	PRESET	38-4 12stRICK
USER	9-1 DropD -1	USER	19-1 OctMetal	PRESET	29-1 BG DRV	PRESET	39-1 NICE DRV
USER	9-2 NYLON St	USER	19-2 LIP MTL	PRESET	29-2 AcGt+BS	PRESET	39-2 CrunchTL
USER	9-3 NICE DRV	USER	19-3 R&R	PRESET	29-3 WAH STRT	PRESET	39-3 f HOLE
USER	9-4 FAT BASS	USER	19-4 BRASS+Gt	PRESET	29-4 HORN Gt	PRESET	39-4 BRT LP
USER	10-1 METAL ST	USER	20-1 LP DRIVE	PRESET	30-1 -1OCT ST	PRESET	40-1 OPEN E
USER	10-2 StudioAG	USER	20-2 SMOKER	PRESET	30-2 BODY	PRESET	40-2 STRATCru
USER	10-3 CrunchTL	USER	20-3 BG CRUNC	PRESET	30-3 TELE MOD	PRESET	40-3 R&R
USER	10-4 ARPEGGIO	USER	20-4 SLOW ATK	PRESET	30-4 CLEAN TL	PRESET	40-4 BG CRUNC

No.	Name
PRESET 41-1	'60sECHO
PRESET 41-2	PHASE LP
PRESET 41-3	CRY TELE
PRESET 41-4	HALF DRV
PRESET 42-1	'60s R&R
PRESET 42-2	ST STACK
PRESET 42-3	NATURAL
PRESET 42-4	BLUES MS
PRESET 43-1	SmallAmp
PRESET 43-2	TELE TW
PRESET 43-3	WahCRUNC
PRESET 43-4	EC LEAD
PRESET 44-1	DeepEcho
PRESET 44-2	BluesDrv
PRESET 44-3	ES WAH
PRESET 44-4	LP WAH
PRESET 45-1	DropD -1
PRESET 45-2	METAL ST
PRESET 45-3	FatMETAL
PRESET 45-4	DropD -2
PRESET 46-1	WAH TL
PRESET 46-2	MetalWah
PRESET 46-3	WAH +7
PRESET 46-4	MTL SOLO
PRESET 47-1	CoolLead
PRESET 47-2	FatBlues
PRESET 47-3	OctMetal
PRESET 47-4	LP DRIVE
PRESET 48-1	FAT 1959
PRESET 48-2	'80s BG
PRESET 48-3	'70s LED
PRESET 48-4	WAH LEAD
PRESET 49-1	AngleWAH
PRESET 49-2	'70s MS
PRESET 49-3	BOOGIE
PRESET 49-4	BLUES
PRESET 50-1	MINI AMP
PRESET 50-2	DRV-@CLN
PRESET 50-3	LIP MTL
PRESET 50-4	SMOKER

No.	Name
PRESET 51-1	TELE DRV
PRESET 51-2	FAT BG
PRESET 51-3	TexsLead
PRESET 51-4	FuzzLead
PRESET 52-1	HARDROCK
PRESET 52-2	DROP D
PRESET 52-3	REVERSE
PRESET 52-4	JB LEAD
PRESET 53-1	OCT DIST
PRESET 53-2	PAF LEAD
PRESET 53-3	POLYDIST
PRESET 53-4	FUZZ BOX
PRESET 54-1	TIGHT MT
PRESET 54-2	CH DRIVE
PRESET 54-3	BEAT DRV
PRESET 54-4	PEDAL+12
PRESET 55-1	LA NYLON
PRESET 55-2	CAPO -4
PRESET 55-3	AcGt MIX
PRESET 55-4	12ST AG
PRESET 56-1	NYLON St
PRESET 56-2	StudioAG
PRESET 56-3	Ac PIEZO
PRESET 56-4	DETUNE12
PRESET 57-1	ALL E
PRESET 57-2	NASH Gt
PRESET 57-3	BANJO
PRESET 57-4	CAPO 7
PRESET 58-1	BASS DRV
PRESET 58-2	PAN SFX
PRESET 58-3	Em9
PRESET 58-4	ROTARY
PRESET 59-1	FAT BASS
PRESET 59-2	ARPEGGIO
PRESET 59-3	HARMO 12
PRESET 59-4	BOWED
PRESET 60-1	DRV BASS
PRESET 60-2	STEP SFX
PRESET 60-3	SlowEcho
PRESET 60-4	OCTAVE24

No.	Name
PRESET 61-1	AnalogGR
PRESET 61-2	12st OCT
PRESET 61-3	BRASS+Gt
PRESET 61-4	SLOW ATK
PRESET 62-1	OCT SFX
PRESET 62-2	SYN LEAD
PRESET 62-3	Bell Mix
PRESET 62-4	BASS AMP
PRESET 63-1	BAMBOO
PRESET 63-2	12st 5th
PRESET 63-3	CRYSTAL
PRESET 63-4	RezoBASS
PRESET 64-1	SPACE DS
PRESET 64-2	MildHorn
PRESET 64-3	NoizLoop
PRESET 64-4	PWM LEAD
PRESET 65-1	SoftLead
PRESET 65-2	DrvSYNTH
PRESET 65-3	GONG
PRESET 65-4	VIRUS